

FIG.1







FIG.2







- * SUB-MENU DISPLAY AREA COORDINATES ON LCD FONT SIZE (18*19)*3ROW = 57PIXEL + MARGIN 3PIXEL = 60PIXEL
- * TV PICTURE DISPLAY AREA (IF FULL) -> 176X220 ALL USED





FIG.6










FIG. 8





- * DIRECT ACCESS FUNCTION
- * **←---** (RETURN TO UPPER MENU): CANCEL KEY

FIG.10



FIG.11A



FIG.11B